



## ALLSAFE FLOORING P/L

Anti-slip manufacturers & applicators  
Factory 2 / 6 Walker Street, Braeside 3195  
Tel: 03 9587 7706 Fax: 1800 466 754  
[info@allsafeflooring.com.au](mailto:info@allsafeflooring.com.au)  
Website: [www.allsafeflooring.com.au](http://www.allsafeflooring.com.au)

### ALLSAFE ANTI-SLIP SYSTEM – 25 SQUARE METRE PACK USE ONLY ON: CERAMIC, QUARRY & MOSAIC TILED

**Thank you for choosing Allsafe anti-slip system.**

**Please read this direction sheet before commencing application.**

**Check the contents of this box. Should there be any shortage or damage please call us on (03) 9587 7706**

**This Slip NO More Pack anti-slip system pack contains FOUR products.**

**Product No.1 ( It green liquid) Product No.2 (yellow liquid) & Product No.3 ( red liquid ). These three products used together will make your slippery floor anti-slip safe.**

**The other Product GMC General Maintenance Cleaner (green liquid) can be used for all types of cleaning applications around your home, including your floors**

**Allsafe AMC ( Anti - Slip Maintenance Cleaner ) – Not Included**

**A specially formulated cleaning product to clean your floor after treatment.**

**SEE ON-GOING ANTI SLIP CLEANING DIRECTION also attached.**

#### **BEFORE YOU START:**

**Remove all items from the area to be treated and sweep up all loose debris.**

**Lay towelling or protected sheet down beside working area to stand equipment on.**

**Make sure you have everything ready before you start. Soft broom, squeegee, watering can, mop & bucket with plenty of clean cold water.**

**During application avoid splashing or walking products onto other floor surfaces as staining may occur. Never allow the products to dry out. Do not apply to hot surfaces.**

**IF DOING 25 SQUARE METRES USE ALL THE LIQUIDS IN EACH BOTTLE**

#### **DIRECTIONS FOR APPLICATION:**

- 1) Apply product No.1 by brushing over shirtings & over surface to be treated.**
- 2) Whilst product No.1 is wet immediately and carefully apply product No.2 over product No.1. Brush the liquids carefully around to avoid splashing walls or equipment.  
The two products mixed together will now start to create the anti-slip effect. The leave on time to produce the required anti-slip effect varies from tile to tile. Between 5 – 10 minutes is all that's required. **DO NOT LEAVE PRODUCTS ON FOR LONGER THEN REQUIRED** as over treatment may cause difficulties in cleaning the floor after treatment. To judge this push your foot with weight into the solutions on the floor. As soon as you feel your foot gripping the anti-slip is completed and step 3 should be done as quickly as possible.**
- 3) Apply product No.3 over the wet surface and brush well in.**
- 4) Immediately rinse the floor with plenty of clean water. Brush or squeegee as much of the waste liquids down the waste drain outlet.**
- 5) Repeat step 4.**
- 6) Mop over floor and skirtings with clean water once or twice and leave to dry.**

#### **THE FLOOR IS NOW ANTI-SLIP SAFE AND READY FOR USE.**

**Depending on the colour and surface a slight dullness or a 'Bloom' maybe visible after the treatment has dried. This is quite normal and will disappear with on-going cleaning.**

**Because the application of theses products are out of our control, Allsafe Flooring cannot and will not except any liability for any injury or damage caused by using these products.**