



ALLSAFE FLOORING P/L

Anti-slip manufacturers & applicators
Factory 2 / 6 Walker Street, Braeside 3195
Tel: 03 9587 7706 Fax: 1800 466 754
info@allsafeflooring.com.au
Website: www.allsafeflooring.com.au

FLOORSAFE ANTI-SLIP SYSTEM – 10 SQUARE METRE PACK USE ONLY ON: TERRAZZO & CONCRETE SURFACES

Please read this direction sheet before commencing application.
Check the contents of this box. Should there be any shortage or damage please call us on
(03) 9587 7706

This Slip NO More Pack anti-slip system pack contains FOUR products.
Product No.1 (green liquid) Product No.2 (yellow liquid) Product No.3 (red liquid) & Product
TC (orange liquid) These four products used together will make your slippery floor anti-slip
safe.

Allsafe AMC (Anti - Slip Maintenance Cleaner) – Not Included
A specially formulated cleaning product to clean your floor after treatment.
SEE ON-GOING CLEANING DIRECTION OVER

BEFORE YOU START:

Remove all items from the area to be treated and sweep up all loose debris.
Lay towelling or protected sheet down beside working area to stand equipment on.
Make sure you have everything ready before you start. Soft broom, squeegee, watering can,
mop & bucket with plenty of clean cold water.

**During application avoid splashing or walking products onto other floor surfaces as staining
may occur. Never allow the products to dry out. Do not apply to hot surfaces.
IF DOING 8 10 SQUARE METRES USE ALL THE LIQUIDS IN EACH BOTTLE**

DIRECTIONS FOR APPLICATION:

- 1) Apply product No.1 by brushing over shirtings & over surface to be treated.
- 2) Whilst wet apply product TC over product No.1. Brush liquids carefully over floor
avoiding splashing walls or equipment. To make sure edges and corners finish up clean
repeat brushing of the liquids in those areas.
- 3) Leave for 5 minutes then rinse products from floor with plenty of clean water.
- 4) Brush excess liquids down drain waste outlet or mop up leaving the floor damp/wet.
- 5) Apply product No.2 over the damp/wet surface. Brush this product well into the
surface.
This product will now start to create the anti-slip effect. The leave on time to produce
the required anti-slip effect varies from surface to surface. Between 3 – 10 minutes is
all that's required. **DO NOT LEAVE PRODUCTS ON FOR LONGER THAN IS REQUIRED** as
over treatment may cause difficulties in cleaning the floor after treatment. To judge
this push your foot with weight into the solutions on the floor. As soon as you feel
your foot gripping the anti-slip is completed and step 6 should be done as quickly as
possible.
- 6) Apply product No.3 over the wet surface and brush well in.
- 7) Immediately rinse the floor with **plenty** of clean water. Brush as much of the liquid
down the waste drain outlet.
- 8) Repeat step 7.
- 9) Mop over floor and skirtings with clean water once or twice and leave to dry.

THE FLOOR IS NOW ANTI-SLIP SAFE AND READY FOR USE.

Depending on the colour and surface a slight dullness or a 'Bloom' maybe visible after the
treatment has dried. This is quite normal and will disappear with on-going cleaning.

Because the application of these products are out of our control, Allsafe Flooring cannot and
will not except any liability for any injury or damage caused by using these products.